

Close Contour Paste

Machine dispensed epoxy paste

Key Properties

- Very fine and homogeneous surface
- Easy to machine, low dust
- Low exotherm, can be applied over a large area in one step
- Layer thickness 40 mm without slump on vertical surfaces

Applications

- Molds
- Master models
- Design and Styling models

Processing Properties

			CP-6070 Resin	CP-6072 Hardener
Color	visual		Brown	White
Mix ratio		parts by weight	100	100
		parts by volume	100	100
Density	ISO 1183	g/cm ³	ca. 0.70	ca. 0.70

			CP-6070 Resin / CP-6072 Hardener
Pot life at 25 °C	1000 ml	min	50 – 60
Layer thickness		mm	40
Machinable after (at 25°C)		h	14

Cured / Mechanical Properties

Cure: 7 days at RT or 14 h at 40°C

			CP-6070 Resin / CP-6072 Hardener
Appearance	visual		Brown
Density	ISO 1183	g/cm ³	ca. 0.75
Shore hardness D	ISO 868		55 – 60
Coefficient of thermal expansion	ISO 11359	10 ⁻⁶ K ⁻¹	70 – 75
Deflection temperature, HDT	ISO 75	°C	45-50 (60-65) ¹⁾
Glass Transition Temperature, Tg	DSC	°C	50-55 (70-75) ¹⁾
Compressive strength	ISO 604	MPa	13 – 18
Compressive modulus	ISO 604	MPa	600 – 800
Flexural strength	ISO 178	MPa	13 – 18
Flexural modulus	ISO 178	MPa	600 – 800
Linear shrinkage*		mm / m	ca. 1.2

*Measured on 20 mm layer thickness after cure 7 days at RT. / ¹⁾ Test pieces were post cured at 80°C for 14 hours.

Close Contour Paste

Machine dispensed epoxy paste

Processing

The processing and material temperature should be between 20-25 °C, never below 18 °C.

Set up parameters for dispensing machine are available on request.

Check the mixing ratio before you start with the application.

Please ensure the constant supply of compressed air.

The longer the hose the higher the material pressure.

Avoid applying over 40 mm at once, for thicker layers it is recommended to apply the 2nd layer after the first one has gelled.

Packaging

RAKU-TOOL® CP-6070 Resin	32 kg in 50L drum / 130 kg in 200L drum
RAKU-TOOL® CP-6072 Hardener	32 kg in 50L drum / 130 kg in 200L drum

Storage

Original containers should be kept tightly sealed and stored at ambient temperatures (15°C to 30°C). If properly stored the products have the shelf-life indicated on the product label.

Partly used containers should always be sealed appropriately and used up as soon as possible.

Handling Precautions

Good workplace ventilation is to be ensured during processing. At the same time, the employer's liability insurance association's industrial hygiene safety regulations regarding the handling of reaction resins and their hardeners are to be observed. Please take heed of the appropriate safety data sheets.
