




IBS-Parts Cleaning Device Type W-250



Description

Heatable Parts cleaning device, with immersion bath function, for the use with IBS-Special Cleaners WAS, with a large work surface.

Article-No.

2120035

Brief info load & tank capacity



Function

By pressing the footswitch the cleaning agent flows through the brush and the soiled small parts will be cleaned from oil and grease. Also as immersion bath applicable. The parts to be cleaned can easily be laid in the tank with liquid by opening the upper work surface.

Advantage

- heatable parts cleaning device for the application of IBS-Special Cleaners WAS
- robust and stable construction
- stainless steel
- for cleaning especially large and heavy parts thanks to high carrying capacity with up to 250 kg
- for the flexible use as immersion bath cleaning combined with manual brush cleaning
- heatable up to 45°C max.
- industrial design

Technical Data

Overall dimensions:	1145 x 670 x 1123 mm (BxTxH closed)
	1145 x 780 x 1490 mm (BxTxH open)
Work surface:	1135 x 660 mm (inside dimensions)
Work height:	929 mm
Load capacity:	250 kg
Temperature:	45°C max.
Filling quantity at least:	45 L
Filling quantity max.:	100 L
Heating output:	2 kW
Electricity supply:	230 V, 50 Hz

