

# IBS-Spray Cleaner WAS 10.100



## IBS-Spray Cleaner WAS 10.100 (former Hot degreaser)

### Description

Liquid, alkaline degreasing water-based agent. Perfect degreasing and cleaning — all in one. Suitable for nearly every surface. Ideal for use in automatic parts washer, spray cleaning equipment, flood cleaning equipment and parts cleaning devices for water-based cleaners.

### Range of application

- Used in branches such as
- ▶ automobile Industry (subcontractor)
  - ▶ truck workshops and construction machines workshops
  - ▶ overhauling of engines in general
  - ▶ metalworking industry
  - ▶ engineering
  - ▶ firms of maintenance of equipment

### Removes the following solings

- For removal of highly adhesive soiling e.g.:
- ▶ oil of every description
  - ▶ cooling lubricant
  - ▶ bore and cutting oil
  - ▶ motor oil
  - ▶ corrosion protection oil
  - ▶ hydraulic oil
  - ▶ fat
  - ▶ native fat
  - ▶ lubricant components
  - ▶ preservative (Wax)
  - ▶ Resin
  - ▶ Crustification and swarfs



After cleaning flush with water, otherwise cleaner residues remain which makes painting — galvanization more difficult.

### Purification process

Ideal for using in IBS-Automatic parts washer, spray cleaning equipment and flood cleaning equipment and parts cleaning devices for water-based cleaners.

### Application method

Concentration 2 - 5%	Cleaning Temperature from 40°C	pH-value 13	Injection pressure 2 - 6 bar	Residence time 3 - 10 minutes

### Application-technical benefits

- ▶ liquid water-based concentrate — no dry chemical (no acid dust)
- ▶ effective high cleaning power due to matched active ingredients
- ▶ suitable for nearly all surfaces, as steel, stainless steel, nonferrous-metal, aluminium, glass, ceramic and thermoplastic synthetical
- ▶ energy-saving — perfect cleaning results starting from 40°C
- ▶ perfect cleaning and degreasing all in one
- ▶ with corrosion protection
- ▶ demulsifying — suitable for oilseparator → longer durability
- ▶ washing active without foam formation
- ▶ easy apportioning and handling
- ▶ no staining
- ▶ ecologically sensitive and user-friendly

Please test on an inconspicuous location before using.

### Available sizes of trading unit

