

IBS-Spray Cleaner WAS Universal 10.500



NO labeling obligation

IBS-Spray Cleaner WAS Universal 10.500

Description

Liquid, neutral degreasing water-based agent, for removing heavy soilings. Ideal for use in automatic parts washer, spray cleaning equipment, flood cleaning equipment and parts cleaning devices for water-based cleaners. Due to its outstanding material compatibility for a wide range of individual cases. Also suitable for ultrasonic cleaners.

Range of application

- Suitable for
- ▶ automobil industry (subcontractor)
 - ▶ truck workshops and construction machines work shops
 - ▶ overhauling of engines in general
 - ▶ metalworking industry
 - ▶ engineering
 - ▶ firms of equipment maintenance
 - ▶ hardening plant

Removes the following soilings

- For removal of highly adhesive soiling e.g.:
- ▶ oil (of every description)
 - ▶ cooling lubricant
 - ▶ bore oil and cutting oil
 - ▶ motor oil
 - ▶ corrosion protection oil
 - ▶ hydraulic oil
 - ▶ fat (native Fat, lubricant components)
 - ▶ swarf
 - ▶ grinding and polishing dust
 - ▶ dust

Purification process

Ideal for using in IBS-Automatic parts washer, spray cleaning equipment and flood cleaning equipment and parts cleaning devices for water-based cleaners.



NEW in the product range!

Application method

Concentration 2 - 5%	Cleaning Temperature from 45°C	pH-value 9	Injection pressure 2 - 6 bar	Residence time 3 - 10 minutes

Application-technical Benefits

- ▶ liquid water-based concentrate — no dry chemical (no acid dust)
- ▶ with corrosion protection (guaranteed from a use of concentration of 5%)
- ▶ effective high cleaning power due to matched active ingredients
- ▶ **no labeling obligation** — harmless use appropriate occupational safety
- ▶ gentle to the material — suitable for sensitive surfaces I parts (lacquered surface brass, copper, zinc, nickel, chrome, aluminium, plastics of every description)
- ▶ demulsifying — suitable for oilseparator → longer durability
- ▶ cleans with temporary rust prevention (with special corrosion protection inhibitors)
- ▶ energy-saving — perfect cleaning results starting from 45°C
- ▶ washing active without foam formation
- ▶ easy apportioning and handling
- ▶ no staining
- ▶ ecologically sensitive and user-friendly
- ▶ free of silicate

Please test on an inconspicuous location before using.

Available sizes of trading unit



Water-based cleaners
Hydrocarbon-based cleaner
Sprays

Further information under www.ibs-scherer.com/